

Appendix GTC 5: Assignments for dynamically allocable capacities



valid for capacity usage as of 1 October 2014

Last update: 31 July 2014

grid point	flow direction	capacity assignment	flow direction
Sp. Rheden	Entry	Eynatten, Broichweiden Süd, WEDAL grid points to end consumers	Exit
Mallnow	Entry	Olbernhau II, Ronneburg	Exit
Mallnow	Entry	Kienbaum	Exit
Kienbaum	Exit	Mallnow	Entry
Olbernhau II	Exit	Mallnow	Entry